

Wireless Presentation System



Quick Installation Guide (WPS-InteractiveP)

Version: 2.0

Date: Feb 06, 2013

1.Package Contents

- WPS Box
- WPS USB Token (Optional)
- Power Adapter (DC +5V, 2.5A)
- Antenna *2
- CD : Quick Installation Guide
- CD : User Manual

2.CD / USB Token Contents

Client Folder

- Software and MobiShow software for Smartphone

Applications Folder


- VAC (For Windows XP Audio Projection)
- VDD (For Virtual Extended Screen)
- PtG Converter (For MobiShow PtG function)
- SNMP Manager(For WPS device management)
- UOIP (USB over IP driver for IWB/Touch panel)

3.Physical Details

- Front Panel




- Rear Panel



4. Installation

- 1) Connect projector VGA/HDMI cable to WPS box VGA/HDMI connector and turn on projector power.




- 2) Turn on WPS box.
 - ◆ When Projector shows the default menu on the screen as below, it indicates the WPS box is ready now.



● Windows




- 1) Make sure your PC WLAN is enabled already, and connect your PC with WPS box.



- 2) Open your browser and it will redirect to WPS main page automatically, or you can enter the IP address to access the WPS web home page.
 - ◆ The default IP address of WPS is **192.168.100.10** or refers to the IP address shown on the left corner of projector screen.



- 3) Download the client software. Please select the "Windows 8/ 7/ Vista / XP" and execute the installation program.
 - ◆ After install the program, WPS shortcut will come out on the PC desktop.




- 4) Make sure your personal firewall allows WPS software to pass through.

5) Enter the **LOGIN CODE** and

- ◆ You can see the login code on the projector screen



6) Click the  button to start projection, or choose one of the numbers (1 to 4) to project to the split screen.




● Mac

- 1) Enable your WiFi and connect to WPS device.



- 2) Execute WPS client software for Mac. (You can find it in WPS USB Token or download it from the WPS web page)
- 3) Launch WPS software and enter the login code.



- 4) Click the  button to start projection.

