

1 Port ExpressCard e-SATA Controller Adapter Card

System Requirements

- ◆ An ExpressCard enabled computer system
- ◆ OS support: Windows® /2000/XP/Server 2003/Vista

The ExpressCard will fit into any ExpressCard . Push the card into slot, until it “clicks”. See your laptop’s documentation for more specific information on plugging ExpressCard adapter .

1. After the card is inserted into the ExpressCard, Windows should automatically detect new hardware. The Found New Hardware wizard should appear.
2. When prompted, insert the included driver CD into your computer and Windows should automatically start searching the CD. Otherwise click “Next” to proceed.
3. Follow any on screen prompts, until the card is successfully installed.

Verifying Installation For Win2k/XP/Vista

1. From the main desktop right –click on my computer then select Manage. In the new computer management window, select device manager from the left window panel
2. Under the “SCSI and RAID Controller(2000/XP) or storage controllers(vista) category, you should see a device called JMicorn JM363.
3. Right-click on that device and select properties and under device status is should say it’s working properly.

Specifications

Bus Interface	ExpressCard 1.0
Form Factor	ExpressCard/34
Connectors	eSATA
Chipset	JMicorn JMB363
Maximum Data Transfer Rate	3 Gb/s
Compatible Operating Systems	Windows® 98SE/ME/2000/XP/Server 2003/Vista